

Soojakaod (püstikute kaupa) „W“-s

Püstiku NR.	Ilma soojust	pööningu soojust	otsasein soojust	täis soojust
1	9955	9535	7995	7795
2	10330	9818	8829	7024
2a	3720	3556	3264	2848
3	1980	1887	1887	1556
3a	1980	1887	1887	1556
Trepp	3370	3033	3033	2696
4	3206	2979	2979	2461
5	1980	1887	1887	1556
5a	1980	1887	1887	1556
6	3720	3560	2848	2848
6a	10330	9818	8829	7024
7	4365	4137	4137	3310
7a	4365	4137	4137	3310
8	10330	9818	8829	7856
8a	3720	3560	2848	2848
Trepp	1980	1887	1887	1556
10	3305	2979	2979	2461
11	1980	1887	1887	1556
11a	1980	1887	1887	1556
12	3720	3556	3556	2848
12a	10330	9818	8829	7024
13	4365	4137	4137	3310
13a	4365	4140	3310	3310
14	10330	9818	8829	7024

15a	1980	1890	1512	1512
Trepp	3375			
16	3301	6450	5160	5160
17	1980	1890	1512	1512
17a	1980	1890	1512	1512
18	3720	3560	2848	2848
18a	10330	9820	8829	7024
19	9955	9535	7995	7995
20	9955	9535	7995	7995
21	10330	9818	8829	7856
21a	3720	3560	2848	2848
22	5050	4545	4545	4040
23	3720	3556	3556	2848
23a	10330	9818	9818	7856
24	4365	4140	3310	3310
24a	4365	4137	4137	3310
25	10330	9818	9818	7856
25a	3720	3556	3556	2848
26	4950	4545	4545	4040
27	3720	3556	3556	2848
27a	10330	9818	9818	7856
28	4365	4137	4137	3310
28a	4365	4137	4137	3310
29	10330	9818	9818	7856
30	4950	4545	4545	4040
31	3720	3556	3264	2848
31a	10330	9818	8829	7856

32

9955

9535

7995

7795